

FUEL LEVEL SENSOR

EMISSION CONTROL (AUX. EMISSION CONTROL DEVICES)

7. Fuel Level Sensor

A: REMOVAL

For removal procedure, refer to "FU" section. <Ref. to FU(H4SO)-59, REMOVAL, Fuel Level Sensor.>

B: INSTALLATION

For installation procedure, refer to "FU" section. <Ref. to FU(H4SO)-59, INSTALLATION, Fuel Level Sensor.>