


7. Clutch Pipe and Hose

A: REMOVAL

- 1) Remove the air cleaner case and air intake duct.
- 2) Drain the clutch fluid. <Ref. to CL-22, Clutch Fluid.>
- 3) Remove the clutch pipe from the clutch hose and master cylinder.
- 4) Pull out the clamp, then remove the clutch hose from bracket.



- (A) Clamp
- (B) Clutch hose

- 5) Remove the hose from operating cylinder.
- 6) Remove the bracket.

B: INSTALLATION


Install in the reverse order of removal.

Tightening torque:

T1: 15 N·m (1.5 kgf-m, 10.8 ft-lb)

T2: 18 N·m (1.8 kgf-m, 13.0 ft-lb)

T3: 25 N·m (2.5 kgf-m, 18.1 ft-lb)



- (A) Clutch pipe
- (B) Clip
- (C) Clutch hose

C: INSPECTION

Check the pipes and hoses for cracks, breakage, or damage. Check the joints for fluid leakage. If any cracks, breakage, damage, or leakage is found, repair or replace the applicable pipe or hose.