


FRONT DOOR GLASS

GLASS/WINDOWS/MIRRORS


4. Front Door Glass

A: REMOVAL


- 1) Remove the front door trim. <Ref. to EI-38, REMOVAL, Front Door Trim.>
- 2) Remove the sealing cover. <Ref. to EB-17, REMOVAL, Front Sealing Cover.>
- 3) Remove the outer mirror assembly. <Ref. to GW-17, REMOVAL, Outer Mirror Assembly.>
- 4) Remove the gusset.




- 5) Remove the stabilizers and trim hooks.




- 6) Remove the rear end of door weather strip and weather strip outer.



- 7) Operate the power window switch to move the glass to position shown in the figure, and then remove the two nuts from service holes.



- 8) Take out the door glass.



CAUTION:

- Do not turn the regulator in closing direction after removal of the glass. Otherwise gear may be disengaged.
- Avoid impact and damage to the glass.

B: INSTALLATION

1) Install in the reverse order of removal.

CAUTION:

Make sure the glass stay is placed securely in sash.

2) Adjust the front door glass. <Ref. to GW-11, ADJUSTMENT, Front Door Glass.>

Tightening torque:

Refer to COMPONENT in General Description. <Ref. to GW-4, FRONT DOOR GLASS, COMPONENT, General Description.>

C: ADJUSTMENT


NOTE:

Before adjustment, ensure that all adjusting bolts of stabilizer, upper stopper, and sash are loosened and door glass is raised so that it is in contact with weather strip.

1) Temporarily tighten one adjusting bolt on one side of rear sash at the midpoint of slotted hole in the inner panel.



2) Temporarily tighten the regulator B-channel in a position at the top of slotted hole.

3) Lower the door glass 10 to 15 mm (0.39 to 0.59 in) from fully closed position. While applying outward pressure of 45.0 ± 5.0 N (4.5 ± 0.5 kgf, 9.9 ± 1.1 lb) (F) to upper edge of glass above midpoint of two outer stabilizers, press the inner stabilizer at pressure of 30 ± 5 N (3.0 ± 0.5 kgf, 6.6 ± 1.1 lb) to the glass, then secure it.




- (1) Full close position
- (2) Stabilizer
- (3) 10 — 15 mm (0.39 — 0.59 in)

4) For adjustment of clearance between front glass and center pillar cover, loosen the nuts (A), and move the glass sash back and forward until clearance becomes the value shown.



- (1) 12 mm (0.472 in)


5) For adjustment of upper and lower ends of center pillar, loosen the adjusting nut (A) of B-channel (B).



FRONT DOOR GLASS


GLASS/WINDOWS/MIRRORS

6) Adjust so that the upper and lower ends of center pillar are the same size.




- (1) Narrow
- (2) Wide
- (3) Glass tilts too far rearward
- (4) Glass tilts too far forward
- (5) Raise B channel
- (6) Lower B channel

7) For glass stroke adjustment, close the door, raise glass until positional relationship between glass and weather strip becomes as shown. And secure the glass so that the upper stopper lightly touches the glass holder.



- (1) 2 — 3 mm (0.079 — 0.118 in)
- (2) 6 mm (0.236 in)

For preventing wind noise, adjust the glass at the position where tip of gusset is raised up a little.




- (A) 0 — 1.5 mm (0 — 0.059 in)

8) After stabilizer adjustment, carry out the glass crimp adjustment. First, visually ensure positional relationship between retainer & molding and glass of the roof side, and then begin with rear sash adjustment. Adjust two adjusting bolts alternately step by step to obtain dimensions shown below (cross-section A).

NOTE:

If two nuts are loosened at the same time, sash moves back and forth. Therefore, when one nut is adjusted, leave the other secured.


9) Make the same adjustment of two adjusting bolts of rear sash.



- (1) 2 — 3 mm (0.079 — 0.118 in)
- (2) 6 mm (0.236 in)

NOTE:

Do not tilt the sash bracket to inner panel during adjustment. Otherwise smooth regulator operation cannot be achieved.



- (1) Sash bracket
- (2) Rear sash
- (3) Adjust a line parallel
- (4) Sash
- (5) Inner panel

10) Make adjustment of front sash in the same manner as that of rear sash.


NOTE:

Although front and rear sashes must, as a rule, be adjusted in the same manner, in some door installation, the adjustment in a different manner may be required. However, adjustment of one sash to the maximum amount and the other to the minimum amount is not permitted. Such adjustment may result in application of excessive load to regulator.

11) After adjustments, tighten the nuts.

12) After adjustment to glass, close the door. If there is a gap between outer lip of gusset and glass surface, adjust the gap with adjusting bolt (A) in lower fitting part of the gusset to prevent generation of wind noise.

13) During adjustments, loosen the other three clamping bolts.



14) After adjustment, tighten the bolts and nuts.