

## 3. Keyless Entry System


### A: SCHEMATIC

#### 1. KEYLESS ENTRY

<Ref. to WI-123, SCHEMATIC, Keyless Entry System.>

### B: ELECTRICAL SPECIFICATION

#### 1. KEYLESS ENTRY CONTROL MODULE




SL-00037

Content	Terminal No.	Measuring condition
Body integrated module	1 (OUTPUT)	Battery voltage is present when pressing the transmitter LOCK/ARM button.
Body integrated module	2 (OUTPUT)	Battery voltage is present when pressing the transmitter UNLOCK/DISARM button.
Security control module	3	—
Security control module	4	—
Door lock switch	5 (INPUT)	0 V is present when operating the door lock switch.
Ignition switch (ON)	6 (INPUT)	Battery voltage is present when ignition switch is turned to ON.
Key warning switch	7 (INPUT)	Battery voltage is present when inserting the key into the ignition switch.
Door unlock switch	8 (INPUT)	0 V is present when operating the door lock switch.
Rear gate latch switch	9 (INPUT)	0 V is present when rear gate is open.
Door switch	10 (INPUT)	0 V is present when any door is open.
Ground	11	0 V is constantly present.
Turn signal light (Left)	12 (OUTPUT)	Battery voltage is present when pressing the transmitter UNLOCK/DISARM or LOCK/ARM button.
Horn relay	13 (OUTPUT)	0 V is present when pressing the transmitter LOCK/ARM button three times within 5 seconds.
Power supply (Back-up)	14	Battery voltage is constantly present.
Power supply (Back-up)	15	Battery voltage is constantly present.
Keyless buzzer	16 (OUTPUT)	0 V is present when pressing the transmitter UNLOCK/DISARM or LOCK/ARM button.
Security control module	17	—
Turn signal light (Left)	18 (OUTPUT)	Battery voltage is present when pressing the transmitter UNLOCK/DISARM or LOCK/ARM button.

# KEYLESS ENTRY SYSTEM

## SECURITY AND LOCKS

### 2. BODY INTEGRATED MODULE



Content	Terminal No.	Measuring condition
Door switch (Except driver's door)	B7 (INPUT)	0 V is present when any door is open (Except driver's door).
Door switch (Driver's door)	B8 (INPUT)	0 V is present when driver's door is open.
Door unlock switch	B11 (INPUT)	0 V is present when operating the door unlock switch.
Door lock switch	B12 (INPUT)	0 V is present when operating the door lock switch.
Keyless entry control module	B13 (INPUT)	Battery voltage is present when pressing the transmitter LOCK/ARM button.
Keyless entry control module	B14 (INPUT)	Battery voltage is present when pressing the transmitter UNLOCK/DISARM button.
Ignition switch (ON)	B19 (INPUT)	Battery voltage is present when ignition switch is turned to ON.
Key warning switch	B20 (INPUT)	Battery voltage is present when inserting the key into ignition switch.
Power supply	A1	Battery voltage is constantly present.
Power supply	A2	Battery voltage is constantly present.
Ground	A4	0 V is constantly present.
Room light	A5 (OUTPUT)	0 V is present when pressing the transmitter UNLOCK/DISARM button.
Door and rear gate lock actuator	A6 (OUTPUT)	Battery voltage is present when pressing the transmitter LOCK/ARM button.
Door and rear gate lock actuator (Except driver side)	A7 (OUTPUT)	Battery voltage is present when pressing the transmitter UNLOCK/DISARM button two times.
Door lock actuator (Driver side)	A8 (OUTPUT)	Battery voltage is present when pressing the transmitter UNLOCK/DISARM button one time.
Ground	A13	0 V is constantly present.

## C: INSPECTION

### 1. SYMPTOM CHART

Symptom	Repair order	Reference
None of the functions of the keyless entry system operate.	1. Check the transmitter battery and function.	<Ref. to SL-14, CHECK TRANSMITTER BATTERY AND FUNCTION, INSPECTION, Keyless Entry System.>
	2. Check the fuse.	<Ref. to SL-15, CHECK FUSE, INSPECTION, Keyless Entry System.>
	3. Check the keyless entry control module power supply and ground circuit.	<Ref. to SL-15, CHECK POWER SUPPLY AND GROUND CIRCUIT, INSPECTION, Keyless Entry System.>
	4. Replace the keyless entry control module.	<Ref. to SL-51, Keyless Entry Control Module.>
The transmitter cannot be programmed.	1. Check the transmitter battery and function.	<Ref. to SL-14, CHECK TRANSMITTER BATTERY AND FUNCTION, INSPECTION, Keyless Entry System.>
	2. Check the ignition switch circuit.	<Ref. to SL-16, CHECK IGNITION SWITCH CIRCUIT, INSPECTION, Keyless Entry System.>
	3. Check the door switch.	<Ref. to SL-16, CHECK DOOR SWITCH, INSPECTION, Keyless Entry System.>
	4. Replace the keyless entry control module.	<Ref. to SL-51, Keyless Entry Control Module.>
The door lock or unlock does not operate. NOTE: If the door lock control system does not operate when using the door lock switch, check the door lock control system. <Ref. to SL-8, INSPECTION, Door Lock Control System.>	1. Check the transmitter battery and function.	<Ref. to SL-14, CHECK TRANSMITTER BATTERY AND FUNCTION, INSPECTION, Keyless Entry System.>
	2. Check the key warning switch.	<Ref. to SL-17, CHECK KEY WARNING SWITCH, INSPECTION, Keyless Entry System.>
	3. Check the door switch.	<Ref. to SL-16, CHECK DOOR SWITCH, INSPECTION, Keyless Entry System.>
	4. Check the output signal to body integrated module.	<Ref. to SL-18, CHECK OUTPUT SIGNAL TO BODY INTEGRATED MODULE, INSPECTION, Keyless Entry System.>
	5. Replace the keyless entry control module.	<Ref. to SL-51, Keyless Entry Control Module.>
The panic alarm does not operate.	1. Check the transmitter battery and function.	<Ref. to SL-14, CHECK TRANSMITTER BATTERY AND FUNCTION, INSPECTION, Keyless Entry System.>
	2. Check the horn operation.	<Ref. to SL-19, CHECK HORN OPERATION, INSPECTION, Keyless Entry System.>
	3. Replace the keyless entry control module.	<Ref. to SL-51, Keyless Entry Control Module.>

# KEYLESS ENTRY SYSTEM

## SECURITY AND LOCKS

Symptom	Repair order	Reference
The buzzer chirp and hazard light do not operate.	1. Check the buzzer chirp function.	<Ref. to SL-15, CHECK BUZZER CHIRP SETTING, INSPECTION, Keyless Entry System.>
	2. Check the buzzer and hazard light operation.	Buzzer <Ref. to SL-19, CHECK KEYLESS BUZZER, INSPECTION, Keyless Entry System.>
		Hazard light <Ref. to SL-19, CHECK HAZARD LIGHT OPERATION, INSPECTION, Keyless Entry System.>
	3. Replace the keyless entry control module.	<Ref. to SL-51, Keyless Entry Control Module.>
The room light operation do not activate.	1. Check the room light operation.	<Ref. to SL-18, CHECK ROOM LIGHT OPERATION, INSPECTION, Keyless Entry System.>
	2. Replace the keyless entry control module.	<Ref. to SL-51, Keyless Entry Control Module.>
The door warning does not operate.	1. Check the door switch.	<Ref. to SL-16, CHECK DOOR SWITCH, INSPECTION, Keyless Entry System.>
	2. Check the buzzer operation.	<Ref. to SL-19, CHECK KEYLESS BUZZER, INSPECTION, Keyless Entry System.>
	3. Replace the keyless entry control module.	<Ref. to SL-51, Keyless Entry Control Module.>

## 2. CHECK TRANSMITTER BATTERY AND FUNCTION

Step	Check	Yes	No
<b>1 CHECK TRANSMITTER BATTERY.</b> 1)Remove the battery from the transmitter. <Ref. to SL-53, REMOVAL, Keyless Transmitter.> 2)Check the battery voltage. <Ref. to SL-53, INSPECTION, Keyless Transmitter.>	Is the voltage more than 2 V?	Go to step 2.	Replace the transmitter battery.
<b>2 CHECK LED OF TRANSMITTER.</b> 1)Press the LOCK/ARM or UNLOCK/DISARM button six times to synchronize with the keyless entry control module. 2)Press the LOCK/ARM button.	Does the LED blink one time?	Go to step 3.	Replace the transmitter. <Ref. to SL-53, REPLACEMENT, Keyless Transmitter.>
<b>3 CHECK LED OF TRANSMITTER.</b> Keep the LOCK/ARM button pressed.	Does the LED blink one time, and then turn on?	Go to step 4.	Replace the transmitter. <Ref. to SL-53, REPLACEMENT, Keyless Transmitter.>
<b>4 CHECK LED OF TRANSMITTER.</b> Press the UNLOCK/DISARM button.	Does the LED blink one time?	Go to step 5.	Replace the transmitter. <Ref. to SL-53, REPLACEMENT, Keyless Transmitter.>
<b>5 CHECK LED OF TRANSMITTER.</b> Keep the UNLOCK/DISARM button pressed.	Does the LED blink two times?	Transmitter is OK.	Replace the transmitter. <Ref. to SL-53, REPLACEMENT, Keyless Transmitter.>

### 3. CHECK BUZZER CHIRP SETTING

Step	Check	Yes	No
<b>1 CHECK BUZZER CHIRP SETTING.</b> 1)Check the current setting of the buzzer chirp. 2)Remove the key from the ignition switch. 3)Close all doors and the rear gate. 4)Press the LOCK/ARM or UNLOCK/DISARM button.	Does the buzzer signal chirp?	Buzzer chirp function is OK.	Go to step 2.
<b>2 CHECK BUZZER CHIRP SETTING.</b> 1)Press the UNLOCK/DISARM button once. 2)Press both the LOCK/ARM and UNLOCK/DISARM buttons for more than 2 seconds. 3)Press the LOCK/ARM or UNLOCK/DISARM button.	Does the buzzer signal chirp?	Buzzer chirp function is OK.	Check the transmitter function. <Ref. to SL-14, CHECK TRANSMITTER BATTERY AND FUNCTION, INSPECTION, Keyless Entry System.>

### 4. CHECK FUSE

Step	Check	Yes	No
<b>1 CHECK FUSE.</b> Remove and visually check the fuse No. 6 (in the main fuse box) and No. 3 (in the fuse and relay box).	Is the fuse blown out?	Replace the fuse with a new one.	Check the power supply and ground circuit. <Ref. to SL-15, CHECK POWER SUPPLY AND GROUND CIRCUIT, Keyless Entry System.>

### 5. CHECK POWER SUPPLY AND GROUND CIRCUIT

Step	Check	Yes	No
<b>1 CHECK POWER SUPPLY.</b> 1)Disconnect the keyless entry control module harness connector. 2)Measure the voltage between the harness connector terminal and chassis ground. <i><b>Connector &amp; terminal</b></i> <i><b>(B176) No. 14, No. 15 (+) — Chassis ground (-):</b></i>	Is the voltage more than 10 V?	Go to step 2.	Check the harness for open circuits and shorts between the keyless entry control module and fuse.
<b>2 CHECK GROUND CIRCUIT.</b> Measure the resistance between the harness connector terminal and chassis ground. <i><b>Connector &amp; terminal</b></i> <i><b>(B176) No. 11 — Chassis ground:</b></i>	Is the resistance less than 10 $\Omega$ ?	The power supply and ground circuit are OK.	Repair the harness.

# KEYLESS ENTRY SYSTEM

## SECURITY AND LOCKS

### 6. CHECK IGNITION SWITCH CIRCUIT

Step	Check	Yes	No
<b>1 CHECK IGNITION SWITCH SIGNAL.</b> 1) Disconnect the keyless entry control module harness connector. 2) Turn the ignition switch to ON. 3) Measure the voltage between harness connector terminal and chassis ground. <b>Connector &amp; terminal</b> <b>(B176) No. 6 (+) — Chassis ground (-):</b>	Is the voltage more than 10 V?	Ignition switch circuit is OK.	Check the harness for open circuits and shorts between the keyless entry control module and ignition relay.

### 7. CHECK DOOR SWITCH

Step	Check	Yes	No
<b>1 CHECK DOOR SWITCH CIRCUIT.</b> Measure the voltage between the keyless entry control module harness connector terminal and chassis ground. <b>Connector &amp; terminal</b> <b>Front and rear side door:</b> <b>(B176) No. 10 (+) — Chassis ground (-):</b> <b>Rear gate:</b> <b>(B176) No. 9 (+) — Chassis ground (-):</b>	Is the voltage 0 V when each door or rear gate is opened?	Go to step 2.	Go to step 3.
<b>2 CHECK DOOR SWITCH CIRCUIT.</b> Measure the voltage between the keyless entry control module harness connector terminal and chassis ground. <b>Connector &amp; terminal</b> <b>Front and rear side door:</b> <b>(B176) No. 10 (+) — Chassis ground (-):</b> <b>Rear gate:</b> <b>(B176) No. 9 (+) — Chassis ground (-):</b>	Is the voltage more than 10 V when each door or rear gate is closed?	The door switch is OK.	Go to step 3.
<b>3 CHECK DOOR SWITCH.</b> 1) Disconnect the door switch harness connector. 2) Measure the resistance between the door switch terminals. <b>Terminals</b> <b>Door switch No. 1 — No. 3:</b> <b>Rear gate latch switch No. 1 — No. 2:</b>	Is the resistance more than 1 M $\Omega$ when the door switch is depressed?	Go to step 4.	Replace the door switch.
<b>4 CHECK DOOR SWITCH.</b> Measure the resistance between the door switch terminals. <b>Terminals</b> <b>Door switch No. 1 — No. 3:</b> <b>Rear gate latch switch No. 1 — No. 2:</b>	Is the resistance less than 1 $\Omega$ when the door switch is released?	Check the harness for open circuits and shorts between the body integrated module and door switch.	Replace the door switch.

## 8. CHECK KEY WARNING SWITCH

Step	Check	Yes	No
<b>1 CHECK FUSE.</b> Remove and visually check the fuse No. 6 (in the main fuse box).	Is the fuse blown out?	Replace the fuse with a new one.	Go to step 2.
<b>2 CHECK KEY WARNING SWITCH CIRCUIT.</b> 1)Disconnect the keyless entry control module harness connector. 2)Insert the key into the ignition switch. (LOCK position) 3)Measure the voltage between the harness connector terminal and chassis ground. <b>Connector &amp; terminal</b> <b>(B176) No. 7 (+) — Chassis ground (-):</b>	Is the voltage more than 10 V?	Go to step 3.	Go to step 4.
<b>3 CHECK KEY WARNING SWITCH CIRCUIT.</b> 1)Remove the key from the ignition switch. 2)Measure the voltage between the harness connector terminal and chassis ground. <b>Connector &amp; terminal</b> <b>(B176) No. 7 (+) — Chassis ground (-):</b>	Is the voltage 0 V?	Key warning switch is OK.	Go to step 4.
<b>4 CHECK KEY WARNING SWITCH.</b> 1)Disconnect the key warning switch harness connector. 2)Insert the key into the ignition switch. (LOCK position) 3)Measure the resistance between the key warning switch terminals. <b>Terminals</b> <b>No. 1 — No. 2:</b>	Is the resistance less than 1 $\Omega$ ?	Go to step 5.	Replace the key warning switch.
<b>5 CHECK KEY WARNING SWITCH.</b> 1)Remove the key from the ignition switch. 2)Measure the resistance between the key warning switch terminals. <b>Terminals</b> <b>No. 1 — No. 2:</b>	Is the resistance more than 1 M $\Omega$ ?	Check the following: • Harness for open circuits and shorts between the key warning switch and fuse • Harness for open circuits and shorts between the keyless entry control module and key warning switch	Replace the key warning switch.

# KEYLESS ENTRY SYSTEM

## SECURITY AND LOCKS

### 9. CHECK ROOM LIGHT OPERATION

Step	Check	Yes	No
<b>1 CHECK ROOM LIGHT OPERATION.</b> Make sure the room light illuminates when the room light switch is turned ON.	Does the room light illuminate?	Go to step 2.	Check the room light circuit.
<b>2 CHECK HARNESS BETWEEN ROOM LIGHT AND BODY INTEGRATED MODULE.</b> 1)Disconnect the body integrated module harness connector and room light harness connector. 2)Measure the resistance between the body integrated module harness connector terminal and the room light harness connector terminal. <i>Connector &amp; terminal</i> <i>(B280) No. 5 — (R52) No. 2:</i>	Is the resistance less than 10 $\Omega$ ?	The room light operation circuit is OK.	Check the harness for open circuits and/or shorts between the body integrated module and room light.

### 10.CHECK OUTPUT SIGNAL TO BODY INTEGRATED MODULE

Step	Check	Yes	No
<b>1 CHECK OUTPUT SIGNAL.</b> Measure the voltage between the keyless entry control module harness connector terminal and chassis ground when UNLOCK/DISARM button of transmitter is pressed. <i>Connector &amp; terminal</i> <i>(B176) No. 2 (+) — Chassis ground (-):</i>	Is the voltage more than 10 V?	Go to step 2.	Replace the keyless entry control module.
<b>2 CHECK OUTPUT SIGNAL.</b> Measure the voltage between the keyless entry control module harness connector terminal and chassis ground when LOCK/ARM button of transmitter is pressed. <i>Connector &amp; terminal</i> <i>(B176) No. 1 (+) — Chassis ground (-):</i>	Is the voltage more than 10 V?	Go to step 3.	Replace the keyless entry control module.
<b>3 CHECK HARNESS BETWEEN KEYLESS ENTRY CONTROL MODULE AND BODY INTEGRATED MODULE.</b> 1)Disconnect the keyless entry control module harness connector and body integrated module harness connector. 2)Measure the resistance between the keyless entry control module harness connector terminal and body integrated module harness connector terminal. <i>Connector &amp; terminal</i> <i>(B176) No. 2 — (B281) No. 14:</i> <i>(B176) No. 1 — (B281) No. 13:</i>	Is the resistance less than 10 $\Omega$ ?	Replace the body integrated module.	Check the harness for open circuit or shorts between the keyless entry control module and body integrated module.

## 11. CHECK HORN OPERATION

Step	Check	Yes	No
<b>1 CHECK HORN OPERATION.</b> Make sure the horn sounds when the horn switch is pushed.	Does the horn sound?	Go to step 2.	Check the horn circuit.
<b>2 CHECK HORN OPERATION.</b> 1) Disconnect the keyless entry control module harness connector. 2) Ground the harness connector terminal with a suitable wire. <i>Connector &amp; terminal</i> <i>(B176) No. 13 — Chassis ground:</i>	Does the horn sound?	Replace the keyless entry control module.	Check the harness for open circuits and/or shorts between the keyless entry control module and horn relay.

## 12. CHECK HAZARD LIGHT OPERATION

Step	Check	Yes	No
<b>1 CHECK HAZARD LIGHT OPERATION.</b> Make sure the hazard light blinks when hazard switch is turned ON.	Does the hazard light blink?	Go to step 2.	Check the hazard light circuit.
<b>2 CHECK OUTPUT SIGNAL.</b> 1) Remove the key from ignition switch. 2) Close all doors and rear gate. 3) Measure the voltage between keyless entry control module harness connector terminal and chassis ground when LOCK/ARM button of transmitter is pressed. <i>Connector &amp; terminal</i> <i>(B176) No. 12, 18 (+) — Chassis ground (-):</i>	Is the voltage more than 10 V?	Check the harness for open or short between keyless entry control module and turn signal lights.	Replace the keyless entry control module.

## 13. CHECK KEYLESS BUZZER

Step	Check	Yes	No
<b>1 CHECK FUSE.</b> Remove and check the fuse No. 2 (located in main fuse box).	Is the fuse blown out?	Replace the fuse with a new one.	Go to step 2.
<b>2 CHECK KEYLESS POWER SUPPLY.</b> 1) Disconnect the connector from keyless buzzer. 2) Measure the voltage between keyless buzzer harness connector and chassis ground. <i>Connector &amp; terminal</i> <i>(F102) No. 2 (+) — Chassis ground (-):</i>	Is the voltage more than 10 V?	Go to step 3.	Check the harness for open or short between fuse and keyless buzzer.
<b>3 CHECK HARNESS BETWEEN KEYLESS BUZZER AND KEYLESS ENTRY CONTROL MODULE.</b> 1) Disconnect the connector from keyless entry control module. 2) Measure the resistance between keyless buzzer and keyless entry control module. <i>Connector &amp; terminal</i> <i>(F102) No. 1 — (B176) No. 16:</i>	Is the resistance more than 10 $\Omega$ ?	Go to step 4.	Repair the harness between keyless buzzer and keyless entry control module.
<b>4 CHECK KEYLESS BUZZER.</b> Make sure that the buzzer sounds when connecting battery positive terminal to No. 2 terminal of keyless buzzer connector and battery ground terminal to No. 1 terminal of keyless buzzer connector.	Does the buzzer sound?	Replace the keyless entry control module.	Replace the keyless buzzer.