## 9. Center Differential

## A: NOTE

For removal, installation and inspection work, refer to "5MT" section. <Ref. to 5MT-50, Center Differential.>