TRANSFER CLUTCH AND EXTENSION (4AT)

3. Transfer Clutch and Extension (4AT)

A: NOTE

For removal, installation and inspection work, refer to "4AT" section. <Ref. to 4AT-79, Transfer Clutch.>, <Ref. to 4AT-75, Extension Case.>