


29.Luggage Floor Mat

A: REMOVAL

Remove the clips, and then detach the rear floor mats and boxes.



B: INSTALLATION

Install in the reverse order of removal.