


1. SRS Airbag



H5M0932A

- |   |                                   |
|---|-----------------------------------|
| (1) Combination switch ASSY with roll connector | (6) Airbag control module         |
| (2) TORX® bolt T30                              | (7) Airbag main harness           |
| (3) Airbag module ASSY (Driver)                 | (8) Front sub sensor harness (RH) |
| (4) Airbag module ASSY (Passenger)              | (9) Front sub sensor harness (LH) |
| (5) TORX® bolt T40                              | (10) Front sub sensor (RH)        |
|   | (11) Front sub sensor (LH)        |

**Tightening torque: N-m (kgf-m, ft-lb)**

**T1: 4.4±1.5 (0.45±0.15, 3.3±1.1)**

**T2: 7.4±2.0 (0.75±0.2, 5.4±1.4)**

**T3: 10±2 (1.0±0.2, 7.2±1.4)**

**T4: 20±4 (2.0±0.4, 14.5±2.9)**

**T5: 25±2 (2.5±0.2, 18.1±1.4)**