


4. Schematic



S4M0057A

- |   |  |                             |
|---|--|-----------------------------|
| (1) ABS control module and hydraulic control unit (ABSCM&H/U) | (9) Front right outlet solenoid valve            | (17) ABS warning light      |
| (2) ABS control module area                                   | (10) Rear left inlet solenoid valve              | (18) Stop light switch      |
| (3) Valve relay   | (11) Rear left outlet solenoid valve             | (19) Stop light             |
| (4) Motor relay   | (12) Rear right inlet solenoid valve             | (20) G sensor               |
| (5) Motor   | (13) Rear right outlet solenoid valve            | (21) Front left ABS sensor  |
| (6) Front left inlet solenoid valve                           | (14) Transmission control module (only AT model) | (22) Front right ABS sensor |
| (7) Front left outlet solenoid valve                          | (15) Diagnosis connector                         | (23) Rear left ABS sensor   |
| (8) Front right inlet solenoid valve                          | (16) Data link connector                         | (24) Rear right ABS sensor  |

**MEMO:**