
1. General Description

A: COMPONENT


1. FIXED GLASS (SEDAN MODEL)



- (1) Windshield glass
- (2) Dam rubber
- (3) Molding

- (4) Rearview mirror mount
- (5) Locate pin
- (6) Rear window glass
- (7) Spring
- (8) Fastener


2. FIXED GLASS (WAGON MODEL)



- (1) Windshield glass
- (2) Dam rubber
- (3) Molding
- (4) Rearview mirror mount
- (5) Locate pin
- (6) Fastener
- (7) Rear quarter glass
- (8) Locate pin

- (9) Glass
- (10) Spring

3. FRONT DOOR GLASS



- (1) Glass
- (2) Door sash (Front)
- (3) Door sash (Rear)
- (4) Weather strip
- (5) Stabilizer (Outer)


- (6) Stabilizer (Inner)
- (7) Regulator ASSY
- (8) Motor ASSY
- (9) Mirror gusset

Tightening torque: N⋅m (kgf-m, ft-lb)

T1: 7.4 (0.75, 5.5)

T2: 13.7 (1.4, 10.1)

4. REAR DOOR GLASS



- (1) Glass
- (2) Door sash (Front)
- (3) Door sash (Rear)
- (4) Weather strip


- (5) Stabilizer (Outer)
- (6) Stabilizer (Inner)
- (7) Regulator ASSY
- (8) Motor ASSY

Tightening torque: N⋅m (kgf-m, ft-lb)

T1: 7.4 (0.75, 5.5)

T2: 13.7 (1.4, 10.1)

5. MIRRORS



(1) Outer mirror

(3) Mount

(5) Mirror

- (2) Inner rearview mirror
- (4) Spring

(6) Scalp cap

B: CAUTION

- When the electrical connectors are disconnected, always conduct an operational check after connecting them again.
- Avoid impact and damage to glass.

C: PREPARATION TOOL

TOOL NAME	REMARKS
Circuit Tester	Used for checking voltage and continuity.
Piano Wire	Used for window glass removal.
Windshield Knife	Used for window glass removal.